






ROOM 21a - ELEVATIONS




ELEVATION A



ELEVATION B




ELEVATION C




ELEVATION D

KEY


 Lighting track

 Use of power point: Indicate which power point you wish to use by circling the desired "PW" symbol



 that can be fixed to. Only these areas can be fixed to.

DO NOT SCALE


SCALE:
1:40 @ A3




ROOM 21b - ELEVATIONS




ELEVATION A



ELEVATION B



ELEVATION C



ELEVATION D

KEY

- Wifi Box
- Lighting track
- PW Double socket power point
- D Data Point (not automatically connected)
- Deliniates wooden panel that can be fixed to. Only these areas can be fixed to.

DO NOT SCALE

SCALE:
1:40 @ A3

